

ABC FOR QUOCUT PROFESSIONAL

(This listing is to assist users to find the various menu options. It is not intended to provide complete details to operate each function and process – for further assistance please contact QUOCUT SUPPORT on 1800 227 335)

Options	Menu access
Address details <ul style="list-style-type: none"> Maintain address details 	System Configuration Company Details <ul style="list-style-type: none"> Use access password Modify as required and SAVE
Aluminium Colour Descriptions <ul style="list-style-type: none"> Descriptions Display in quotations 	Setup Aluminium Colour Descriptions <ul style="list-style-type: none"> View/update Modify descriptions Select product as appropriate and SAVE
Component pricing <ul style="list-style-type: none"> Generic product 	Setup Components <ul style="list-style-type: none"> Search by code View/Update – modify pricing and SAVE
Configurations options <ul style="list-style-type: none"> Modify glass minimums View configuration options 	Setup Configurations <u>Glass Minimums</u> <ul style="list-style-type: none"> Select configuration Select options Modify glass minimum and SAVE <u>Configuration Options</u> <ul style="list-style-type: none"> View options applicable
Commercial Labour	Setup Components LAB <ul style="list-style-type: none"> Modify costs
Customers	Select Customer menu option <ul style="list-style-type: none"> Add or modify as required and SAVE
Delivery Docket	Quotes Current <ul style="list-style-type: none"> Generate an invoice/delivery docket Select print Add a note if required and PRINT
Diary Notes <ul style="list-style-type: none"> Audit trail for quote calculation Audit trail for cost analysis Add notes and set reminders 	Quotes Current <ul style="list-style-type: none"> Select Diary Notes option View or add Select reminder if required and SAVE
Extrusion – standard lengths <ul style="list-style-type: none"> Lock individual lengths 	Setup Components <ul style="list-style-type: none"> Search by code View/Update – modify as required and SAVE Select Lock
Formulae variances <ul style="list-style-type: none"> Modify formulae 	Setup Configurations <ul style="list-style-type: none"> Highlight configuration View/Update – modify as required and SAVE
Full Bar Roundup (FBR) Markup	System Configuration System Options <ul style="list-style-type: none"> Use access password Modify percentage and SAVE
Full Bar Roundup (FBR) Default	Setup Components <ul style="list-style-type: none"> Search by code View/Update – select FBR default and SAVE
Finish Surcharge	System Configuration System Options <ul style="list-style-type: none"> Use access password Select exclude Finish Surcharge and SAVE
Glass <ul style="list-style-type: none"> Glass types Glass pricing Export set up details 	Setup Glass <ul style="list-style-type: none"> Glass Types Glass Price Categories Minimums Glass Export Setup Double Glazing

ABC FOR QUOCUT PROFESSIONAL

(This listing is to assist users to find the various menu options. It is not intended to provide complete details to operate each function and process – for further assistance please contact QUOCUT SUPPORT on 1800 227 335)

Options	Menu access
<p>Invoices Generate an invoice from the current quote menu <i>(Note – invoices/Delivery Dockets can be viewed from the current quote screen or from the Invoice menu.)</i></p>	<p>Select Invoice Menu</p> <ul style="list-style-type: none"> • Modify and print an invoice • Modify terms and bank details • Print a reminder • View outstanding invoices • Print a delivery docket
<p>Labour default times</p> <ul style="list-style-type: none"> • Labour default times (windows, doors, showers and robes only) 	<p>Setup Configuration Types</p> <ul style="list-style-type: none"> • Select group • Modify default times <p><i>(Note – platinum louvres have a separate menu for labour times)</i></p>
<p>Labour defaults applied</p> <ul style="list-style-type: none"> • Apply labour default times 	<p>Setup Configuration Types</p> <ul style="list-style-type: none"> • Tag group/s • Select Default Labour • Tag labour types • Apply (tagged types and groups)
<p>Labour rates</p>	<p>Setup Components</p> <ul style="list-style-type: none"> • Search for LAB • View/update – modify pricing and SAVE
<p>Labour modifications</p>	<p>Setup Configurations</p> <ul style="list-style-type: none"> • Select Labour • View/update as required to modify • Lock labour and SAVE
<p>Licensing details</p> <ul style="list-style-type: none"> • Determines product and pricing structure 	<p>System Configuration Name Details</p> <ul style="list-style-type: none"> • Modify if necessary • Select CHECK OK SAVE
<p>Look up List</p>	<p>Setup Configurations</p> <ul style="list-style-type: none"> • Select Lkup – choose item for default
<p>Louvre labour</p>	<p>Setup Louvres</p> <ul style="list-style-type: none"> • Select configuration • Access louvre labour icon • Modify as required and SAVE
<p>Louvre Blades and Galleries</p>	<p>Setup Louvres</p> <ul style="list-style-type: none"> • Gallery icon for pricing • Blade icon for pricing
<p>Markups (Price Bands) The markup percentage will in general be applied to all costs, (materials and labour). Security has a separate function for markups on on materials and labour, and Louvres has a separate function for markup on labour.</p>	<p>Setup Configuration Types</p> <ul style="list-style-type: none"> • Tag groups as appropriate • Select Default Markup • Modify or add as required • Apply to tagged groups
<p>Orders</p>	<p>Orders</p> <ul style="list-style-type: none"> • View – To be ordered • Process an order • Update supplier details
<p>Panel Limitations</p>	<p>Setup Configurations Panels</p> <ul style="list-style-type: none"> • View parameters for height, width and area

ABC FOR QUOCUT PROFESSIONAL

(This listing is to assist users to find the various menu options. It is not intended to provide complete details to operate each function and process – for further assistance please contact QUOCUT SUPPORT on 1800 227 335)

Options	Menu access
Powder coat (third party) <ul style="list-style-type: none"> Select charging option Modify pricing 	System Configuration System Options <ul style="list-style-type: none"> Select appropriate area type and SAVE Setup Aluminium Colour (Pricing) <ul style="list-style-type: none"> Select SPEC Spec Prices Add or modify pricing and SAVE
Price Bands	See markups
Quote numbering and ID	System Configuration System Options <ul style="list-style-type: none"> Use access password Modify as required and SAVE
Reports <ul style="list-style-type: none"> Material usage Job Analysis 	Reports menu option <ul style="list-style-type: none"> Complete details Select Report to print <i>(Note this option is only valid if the job analysis function has been used in the quotation screen)</i>
Reveals	Setup Reveals <ul style="list-style-type: none"> Add new and SAVE View update to modify pricing and SAVE
Security Labour	Setup Security <ul style="list-style-type: none"> Highlight configuration Select labour – modify as required and SAVE
Security Markups	Setup Security Markups <ul style="list-style-type: none"> Highlight security type View/update – modify as required and SAVE
Staff details for quotations and diary notes	Setup Sales representatives Setup Staff <ul style="list-style-type: none"> Add or modify details and SAVE
Stock Code	Setup Components <ul style="list-style-type: none"> Select search icon and search by code
Terms & Conditions	Setup Quote Defaults Margins etc <ul style="list-style-type: none"> Modify as required and SAVE
Updating QuoCut <ul style="list-style-type: none"> Update (File used QCUPD) Pricing (File used QCPRICE) Library information (File used LIB1) Files should be saved to the Root Directory OR a Folder specifically for these files (NOT the QC folder).	File Update Control Panel <ul style="list-style-type: none"> (1) Select (UPD - Path will be where QCUPD is saved (e.g. C:\)) (2) Select Pric – Path will be where the QCPRICE is save (e.g. C:) (3) Select Lib - Path will be where LIB1 saved (e.g. C:) <i>(Note – use the browse button to find the correct path destination if unsure)</i>
Wardrobe panels <ul style="list-style-type: none"> Add new panel types Modify pricing 	Setup Wardrobes <ul style="list-style-type: none"> Add Complete details and SAVE Add price in cost field and SAVE
Wastage <ul style="list-style-type: none"> Modify by individual group Add percentage by summary 	Setup Component Groups <ul style="list-style-type: none"> Highlight as appropriate Either view/update and modify OR select Tag Summary and then select wastage
Wind details (This option is only used when showers and robes are exclusive products)	System Configuration System Options <ul style="list-style-type: none"> Select No Wind details and SAVE